

MAGNIFIER LAMP

NO.:8066LED

Thank you very much for purchasing our Magnifying Lamp.

The Magnifying Lamp is ideal for precise work in home, office and workshop as well as a lot of other important places.

Before using the Magnifying Lamp, please read the following instructions.

1. Important data:

- A. Magnifier: 127mm diameter, 3 or 5 diopter
- B. Voltage: AC 220-240V 50Hz
- C. Light source: 90PCS LED

2. How to use:

- A. Before use, remove all packing from around the lamp.
- B. Put the lamp on the horizontal table.
- C. Insert the plug into a conveniently located electrical socket.
- D. Switch on using the ON/OFF switch located on the surface of the base.
- E. To place the head in the desired position.

3. Caution for safe using:

- A. Indoor use only.
- B. Environment temperature: $-10^{\circ}\text{C}\sim 40^{\circ}\text{C}$.
- C. Humidity: 95%.
- D. Never disassemble the magnifying lamp unless you are a qualified electrician.
- E. Plug must be taken out while repairing the magnifier lamp.
- F. Never leave the lens unattended in direct sunlight or where light can shine through it. This constitutes a fire hazard.
- G. If the external flexible cable or cord of this magnifier lamp is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

